### **Product information**

12, 2013

### How to do 78rpm with Pro-Ject turntables

- Pro-Ject offers turntables that are able to play 78rpm records
- Following pages show 2 charts with current and discontinued Pro-Ject turntables and their ability to play 78rpm records
- Some will do all speeds directly out of the box (A), with no additional accessory needed
- Some will need special accessories (B or C or D)
- Some turntables can not be converted for 78-use (E).
- CAUTION! Playback of 78rpm records will damage a standard stylus for 33 or 45rpm records! Special dedicated 78-needles are available for many MM cartridges! (see examples >>>)
- Drive pulley exchange can be reversed easily!
- If you are in doubt, consult your specialised Pro-Ject dealer!





10" grammophone record 78rpm

12" LP 33rpm

7" single 45rpm





set includes pulley and drive belt "square"

SRP 19,00 €

## C: 33 & 45 & 78 Addition of Speed Box S and exchange of standard drive pulley to Pulley SB



# <u>D: 33 & 45 & 78</u> Addition of Speed Box DS and exchange of standard drive pulley to Pulley SB



### **Product information**

12, 2013

Aktuelle Plattenspieler:	33/45/78 U/mim ohne weiteres Zubehör	33/78 U/min (kein 45) mit "78 Pulley Set"	33/45/78 U/min mit Speed Box S & "Pulley SB"	33/45/78 U/min mit Speed Box DS & "Pulley SB"	78 U/min	empfohlene 78er Ersatznadel für
	A	В	C	D	E	vormontierten
	^			_		Tonabnehmer
1 Anny (20 Jahre PJ)/OrtSuperOM10		<b>√</b>	✓	✓		OM78
1 Xpression Carbon 1 Xpression Carbon Phono USB/Ort OM10		<b>V</b>				OM78
1 Xpression Carbon/Ort 2M Red		· /				2M78
1 Xpression Carbon Classic		1				**
1 Xpression Carbon Classic/Ort 2M Silver		✓				2M78
1 Xpression III Comfort/Ort 2M Red	✓					2M78
2 Xperience Basic +/Ort MC 25 E					<b>V</b>	
2 Xperience Classic/Acryl 2 Xperience Acryl SP1/Ort Rondo Red					<b>✓</b>	
2 Xperience Acryl SP2/Ort Salsa					· ·	
2 Xperi Classic/Acryl/Sum Blue P No. 2					<b>✓</b>	
2 Xperi Classic/Ort Rondo Red					✓	
2 Xperi Classic Acryl/Ort Rondo Red					✓	
2 Xperi Classic/Ort 2M Red					<b>√</b>	
2 Xperi Classic Acryl/Ort 2M Red					<b>✓</b>	
2 Xperi Classic SP/Ort 2M Bronze 2 Xperi Classic Acryl SP/Ort 2M Bronze					<b>*</b>	
2 Xperi Classic SP/Ort 2M Bronze					· ·	
2 Xperi Classic Acryl SP/Ort 2M Bronze					<b>√</b>	
6 PerspeX					✓	
6 PerspeX SP/Ort Valencia					✓	
6 PerspeX Anny/Ort Valencia					✓	
6 PerspeX Anny/Ort MC30SupermkII					✓	21170
Debut Carbon Int-DC (Basic)/Ort OM10 Debut Carbon Int-DC (Basic)/PhUSB/Ort OM10	+	<b>√</b>				OM78 OM78
Debut Carbon Int-DC (Basic)/Ph05B/Ort 0M10  Debut Carbon Int-DC (Premium)/Ort 2M Red		<b>✓</b>				2M78
Debut Carbon Esprit Int-DC /Ort 2M Red		· /				2M78
Debut Carbon Esprit SB-DC /Ort 2M Red	✓					2M78
Debut Carbon Int-230 volt (Basic)/Ort OM10		✓		✓		OM78
Debut Carbon Int-230 volt (Basic)/PhUSB/Ort OM10		✓				OM78
Debut Carbon Int-230 volt (Premium)/Ort 2M Red		<b>√</b>		<b>√</b>		2M78
Debut Carbon Esprit Int-230 volt /Ort 2M Red Debut Carbon US-16 volt (Basic)/Ort OM10		<b>✓</b>	<b>✓</b>	<b>✓</b>		2M78 OM78
Debut Carbon US-16 volt (Basic)/PhUSB/Ort OM10		<b>✓</b>	· ·	•		OM78
Debut Carbon US-16 volt (Premium)/Ort 2M Red		<b>√</b>	<b>✓</b>	<b>✓</b>		2M78
Debut Carbon Esprit US-16 volt /Ort 2M Red		✓	✓	✓		2M78
Elemental /Ort OM5E					✓	
Elemental Phono USB/Ort OM5E					<b>√</b>	
Essential II Basic/Ort OM5E					<b>✓</b>	
Essential II Basic/Phono USB/Ort OM5E Essential II Premium/Ort 2M Blue					<b>→</b>	
Essential II Premium/Phono USB/Ort 2M Blue	+				· ·	
Juke Box/Ort OM 5E		<b>√</b>	<b>✓</b>	✓		OM78
Juke Box Esprit/Ort Alpha		✓	✓	✓		**
RPM 1.3 Genie/Ort OM3E					<b>√</b>	
RPM 1.3 Genie/Ort 2M Red		,	,		✓	21172
RPM 5 SP/Ort Salas	-	<b>√</b>	<b>√</b>	<b>✓</b>		2M78 **
RPM 5 SP/Ort Salsa RPM 5.1 SP/Ort 2M Blue	+	<b>V</b>	<b>✓</b>	<b>✓</b>	-	2M78
RPM 5.1	+	<b>✓</b>	· ·	· ·		21V1 / O
RPM 5.1/Ort 2M Red	1	· /	· /	· ·		2M78
RPM 5.1 SP/PJ Pick it MC1H		✓	✓	✓		**
RPM 9.1					✓	
RPM 9.1 Acryl					✓	
RPM 9.1 SP 1/Ort Rondo Red					<b>√</b>	
RPM 9.1 SP 2/Sum Blue P No. 2 RPM 9.2 Evolution	-				<b>✓</b>	
RPM 10.1 Evolution	+				<b>✓</b>	
Signature 10					· /	
Signature 12					✓	
Xtension 9 Evolution					✓	
Xtension 10 Evolution/Sum Blue P No. 2	<b>√</b>					**
Xtension 10 Evolution	<b>√</b>					**
Xtension 12 Evolution	✓	L	L		L	

#### >>> Legende



B 78 U/min durch Ersatz des Schwungrades durch "78 Pulley Set" / 33 & 78 (kein 45 U/min)

C 78 U/min durch Ersatz des Schwungrades durch "Pulley SB" und zusätzlich Speed Box S (geeignet für Plattenspieler mit 16V AC Motor)

78 U/min durch Ersatz des Schwungrades durch "Pulley SB" und zusätzlich Speed Box DS (geeignet für Plattenspieler mit 16V oder 230V AC Motor)

E 78 U/min nicht verfügbar (kein Pulleytausch möglich)

Für diesen Plattenspieler nicht verfügbar

\* Nur möglich, wenn passender Tonabnehmer montiert ist (Austausch des vormontierten Tonabnehmers ist möglich)

## **Product information**

12, 2013

			33/45/78 U/min	33/45/78 U/min		
	33/45/78 U/mim		mit	mit	10001033	empfohlene
	ohne weiteres Zubehör	(kein 45) mit "78 Pulley Set"	Speed Box S & "Pulley SB"	Speed Box DS & "Pulley SB"	78 U/min nicht möglich	78er Ersatznadel für
nicht mohr überell erhöltlich:	100000000000000000000000000000000000000			200 10 1000000	The last of the la	vormontierten
nicht mehr überall erhältlich:	Α	В	С	D	E	Tonabnehmer
0.5		✓	✓	✓		**
0.5 Phono		<b>√</b>				**
1.2	+	<b>✓</b>	<b>✓</b>	<b>✓</b>		**
1.2.E	+	<b>→</b>	· ·	•		**
1.2 C/Sum Oyster		<b>✓</b>	<b>✓</b>	✓		**
1 Xpression		✓	✓	✓		**
1 Xpression II		<b>√</b>	<b>√</b>	<b>✓</b>		**
1 Xpression II/AT 95E		<b>√</b>	<b>✓</b>	<b>✓</b>		**
1 Xpression III/AT AT95E 1 Xpression III C/AT AT95E	+	<b>✓</b>	· ·	<b>∨</b>		**
1 Xpression III	+	· /	· ·	· /		**
1 Xpression III/Ort 2M Red		<b>✓</b>	<b>✓</b>	<b>✓</b>		2M78
1 Xpression Classic		✓	✓	✓		**
1 Xpression Classic/Ort 2M Red		<b>√</b>	<b>√</b>	<b>√</b>		2M78
2	-	✓	<b>✓</b>	✓		**
2 Xperience SP/ OrtMC15SupmkII 2 Xperience C/Ort 510MkII	+				<b>√</b>	
2 Xperience	+				<b>✓</b>	
2 Xperience SP1/Ort Rondo Red	1				<b>✓</b>	
2 Xperience SP2/Ort Salsa					<b>✓</b>	
2 Xperience Comfort/Ort 2M Red					✓.	
2 Xperience Comf/Sum Blue P No. 2	1				<b>V</b>	
2 Xperience Comfort/Ort Rondo Red 2.9 SP (Wood)/Sum Blue P No. 2					✓	**
2.9 Wood)/Sum Blue P No. 2	-	<b>√</b>	<b>✓</b>	<b>✓</b>		**
2.9 Classic		· /	· ·	· /		**
6		✓	<b>√</b>	✓		**
6.1		✓	✓	✓		**
6.9		✓	✓	✓		**
6.9 SP/Sum Blue P No.2		✓	<b>✓</b>	✓		**
Aspect 2011 - wie Xperience Basic + Debut/Ort OM5E	+	<b>✓</b>	<b>✓</b>	<b>✓</b>	✓	OM78
Debut II/Ort OM5E		· ·	· ·	· ·		OM78
Debut II (III) Phono/Ort OM5E		<b>√</b>				OM78
Debut SE II/Ort 510MkII		✓	✓	✓		**
Debut III/Ort OM5E		<b>√</b>	<b>√</b>	<b>✓</b>		OM78
Debut III E/Ort OM5E		<b>√</b>	<b>✓</b>	✓		OM78
Debut III Phono USB/Ort OM5E Debut III Phono SB/Ort OM5E		· ·				OM78 OM78
Debut III Esprit/Ort Alpha	<del>'</del>	<b>✓</b>	<b>✓</b>	<b>✓</b>		**
Debut SE II/Ort 510MkII		<b>√</b>	<b>✓</b>	✓		**
Debut III SE/Ort OM10		✓	✓	✓		OM78
Essential/Ort OM5E					✓	
Essential/Phono USB/Ort OM5E					<b>√</b>	
Essential Basic/Ort OM5E Essential Basic/Phono USB/Ort OM5E					<b>√</b>	
Essential Premium/Ort 2M Blue	+				<u> </u>	
Essential Premium/Phono USB/Ort 2M Blue					✓	
Perspective					<b>√</b>	
Perspective SB					✓.	
Perspective Anny/Sum Blue Point No.2	-				<b>√</b>	
Perspective II RPM 1 Genie/Ort OM3e	+				<b>√</b>	
RPM 1 Genie/Ort Alpha					<b>→</b>	
RPM 1 Genie/Ort 2M Red	1				✓ ·	
RPM 4/Pro K4		✓	✓	✓		**
RPM 4/AT AT95E		✓	✓	<b>√</b>		**
RPM 5	-	<b>√</b>	<b>V</b>	<b>✓</b>		**
RPM 5/Ort 2M Red RPM 5 SP/Ort Salsa	+	<b>√</b>	<b>√</b>	<b>✓</b>		**
RPM 5 SP/Ort Salsa RPM 5 SP/PJ Pick it MC1H	+	<b>✓</b>	· ·	· ·		**
RPM 5/AT AT95E	1	·	·	<i>✓</i>		**
RPM 5 SP/Ort X1-MC		✓	✓	✓		**
RPM 6			✓	✓		**
RPM 6 SB	<b>V</b>					**
RPM 6.1 SB	<b>√</b>					**
RPM 6.1 SB SP/Ort Samba RPM 9	+ <b>*</b> -				<b>√</b>	
RPM 9X	+				<b>▼</b>	
RPM 9XP					<b>√</b>	
RPM 10					✓.	
Studie					✓	