
TV Floor Stand





- Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.
- ⚠ CAUTION: Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- possible injury.

 . Mounts must be attached as specified in assembly instructions. Improper installation may result in damage or serious personal injury.
- . Safety gear and proper tools must be used. This product should only be installed by professionals.
- . Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- . Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws.
- . This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- . This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.

MAINTENANCE: Check that the product is secure and safe to use at regular intervals (at least every three months)

SWB7250 / SWB7260

VESA Compatible 200x200 300x200 300x300 400x200 400x300 400x400







Sinox Europe A/S Troensevej 11. DK-9220 Aalborg www.sinox-europe.com

