AT-VMx SERIES REPLACEMENT & UPGRADE STYLI MATRIX

The cartridge becomes worn after an extended period of play(3), even the finest diamond stylus. Our VM cartridges can be used again for a long time by only replacing the stylus. Our renewed VM cartridges series is composed of 7 styli and 3 types of bodies. Not only is it not necessary to buy the cartridge itself, but you can also enjoy the experience of upgrading your stylus, or trying a new cartridge / stylus combination.



_Cartridge Body	Purchased Cartridge	Special Line Contact Stylus Boron Cantilever AT-VMN60xSL	Shibata Stylus Boron Cantilever AT-VMN50xSH	MicroLine [®] Stylus Boron Cantilever AT-VMN45xML	MicroLine® Stylus Aluminum Tapered Cantilever AT-VMN40xML	Elliptical Nude Stylus Aluminum Cantilever AT-VMN30xEN	Elliptical Bonded Stylus Aluminum Cantilever AT-VMN20xEB	Conical Bonded Stylus Aluminum Cantilever AT-VMN10xCB	3mil Conical Bonded Stylus Aluminum Cantilever AT-VMN70xSP
AT-VM700x	AT-VM760xSL	Standard Replacement	Becomes AT-VM750xSH	Becomes AT-VM745xML	Becomes AT-VM740xML	Compatible	Compatible	Compatible	Possible ⁽¹⁾
	AT-VM750xSH	Upgrade to AT-VM760xSL	Standard Replacement	Becomes AT-VM745xML	Becomes AT-VM740xML	Compatible	Compatible	Compatible	Possible ⁽¹⁾
	AT-VM745xML	Upgrade to AT-VM760xSL	Upgrade to AT-VM750xSH	Standard Replacement	Becomes AT-VM740xML	Compatible	Compatible	Compatible	Possible ⁽¹⁾
	AT-VM740xML	Upgrade to AT-VM760xSL	Upgrade to AT-VM750xSH	Upgrade to AT-VM745xML	Standard Replacement	Compatible	Compatible	Compatible	Possible ⁽¹⁾
AT-VM500x	AT-VM530xEN	Compatible	Compatible	Compatible	Compatible	Standard Replacement	Becomes AT-VM520xEB	Becomes AT-VM510xCB	Possible ⁽¹⁾
	AT-VM520xEB	Compatible	Compatible	Compatible	Compatible	Upgrade to AT-VM530xEN	Standard Replacement	Becomes AT-VM510xCB	Possible ⁽¹⁾
	AT-VM510xCB	Compatible	Compatible	Compatible	Compatible	Upgrade to AT-VM530xEN	Upgrade to AT-VM520xEB	Standard Replacement	Possible ⁽¹⁾
AT-VM600x specialized for mono	AT-VM610xMONO	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Standard Replacement	Becomes AT-VM670xSP
	AT-VM670xSP	Possible not recommended* ⁽²⁾	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Possible not recommended ^{*(2)}	Becomes AT-VM610xM0N0	Standard Replacement

(1) Becomes stereo wiring SP cartridge. Since the SP records only have monaural modulation, using mono body would be recommended.

(2) When playing the earliest mono LPs, there is a possibility that the stylus will touch the bottom of a record groove and produce unwanted noise.

*Lifetime of the replacement stylus is approx. 300 to 500 hours for Conical, 300 hours for Elliptical, 1000 hours for MicroLine *, and 800 hours for Shibata and Special Line Contact.

It is possible to combine an AT-VMx series replacement stylus with a cartridge body from the old VM series, but its performance and sound quality will differ from the latest lineup combinations.